

The Designated Hitter

Assembly Instructions



What is in the Box:

1. The Designated Hitter Upper Body	2. (2) 2 $\frac{3}{4}$ " Bolts
3. The Designated Hitter Lower Body	4. (2) 3" Bolts
5. Plastic Belt Front and Back	6. (2) 3 $\frac{1}{4}$ " Bolts
7. 8-sided, black, rubber base	8. (3) Wing Nuts
9. (4) Steel Bolts	10. (3) Nuts
11. (4) Large Washers	12. Orange cord
13. $\frac{1}{2}$ "Screw	

Required Tools:

9/16" Open end wrench
7/16" Open end Wrench
Philips head Screwdriver

Attaching the 8-sided base to The Designated Hitter Lower Body

1. Align the pre-drilled holes in the 8-sided base (7) with the threaded holes in The Designated Hitter Lower Body (3). Be sure to have the recessed side of the base facing away from The Designated Hitter Lower Body (3).
2. Insert a Steel Bolt (9) through a Large Washer (11), the recessed portion of the 8-sided-base (7) and into the threaded holes of The Designated Hitter Lower Body (3). Use a 9/16" Open End Wrench to tighten the Steel Bolt. **DO NOT OVER TIGHTEN.**
3. Repeat for steps 1 and 2 for the other three bolts (9).

Attaching The Designated Hitter Upper Body to The Designated Hitter Lower Body

1. Align the Black Plastic Belt (5) on The Designated Hitter Lower Body (3) which is tapered toward the back.
2. Insert the 3 $\frac{1}{4}$ " Bolt (6) through the front of the Plastic Belt (5), The Designated Hitter Lower Body (3), Back of the Plastic Belt and secure it in place with a Nut (10) using a 7/16" Open End Wrench to fasten. Be sure to have the head of the bolt in the front and fasten the nut in the back.
3. Take the 3" Bolt (4) and place it in the middle hole of the belt and fasten in the same manner as step 2.
4. Take the 2 $\frac{3}{4}$ " bolts (2) and place it in the third hole of the belt. Fasten in the same manner as step 2.
5. Align The Designated Hitter Upper Body (1) to the holes in the top of the belt, tapered from front to back.
6. Take the 3 $\frac{1}{4}$ " bolt (6) and place it in the first hole of the belt and fasten using the Wing Nut (8). Again be sure to place the head of the bolt in front and tighten the Wing Nut in the back.
7. Take the 3" Bolt (4) and repeat step 6.
8. Take the 2 $\frac{3}{4}$ " Bolt (2) and repeat step 6.

Attaching the Inside Pitch Target

1. Find the Threaded Hole on the elbow of The Designated Hitter Upper Body (1) and use the $\frac{1}{2}$ " screw (13) to attach the Orange Cord (12) to create the inside pitching target.

Pitch With A Purpose™